

Test Instruction of HCHO Sensor





1. Prepare necessary accessories

- 1) Testing Board
- 2) Connecting Cable (Android-USB cable and Testing Cable)
- 4) HCHO Sensor
- 5) Computer
- 6) Serial Operator



2. Connection

- 1) Connect the sensor and testing board by testing cable
- 2) Connect the testing board and computer by Android-USB cable

As show in below picture:









3. Open serial operator

				Click this one					
💀 Serial Operator-ss									
文件(F) 命令(C) 工具	(S) 收藏夹(C) 选项(N)	帮助(H)		/				
		1		× (E			
添加 解压到	测试 查看	删除	查找	向导 信	1日描病:	毒 注释	保护	自解压格式	
↑ 🚰 Serial Operator-sscom 5.13.1.rar - RAR 4.x 压缩文件, 解包大小为 456,154 字节									
名称	~			大小	压缩后大小	 类型		修改时间	CRC32
1.						文件夹			
sscom51.ini			¥	5,082	1,822	配置设置		2020/9/2 22:22	3B4C497D
sscom5.13.1.exe				451,072	417,195	应用程序		2017/5/26 23:	9FA614B4
				_					

1 41

• • • •



1)Setting: Choose the correct COM and click OpenCom

SSCOM V5.13.1 Serial/Net data debugger,Author:Tintin,2618058@qq.com

PORT COM_Settings Display Send_Data Multi_Strings Tools Help 联系作者 PCB打样









2)Send the command, and analyze the result according to protocol.

SSCOM V5.13.1 Serial/Net data debugger,Author:Tintin,2618058@qq.com

PORT COM_Settings Display Send_Data Multi_Strings Tools Help 联系作者 PCB打样

ClearData OpenFile	SendFile Stop ClearSend OnTop Fulsh SaveConfig EXT	_								
ComNum COM14 USB Serial Port 💌	🔽 HEXShow SaveData 🔽 ReceivedToFile 🔽 SendHEX 🔽 SendEvery: 1000 ms/Tim AddCrLf	2								
CloseCom Con More Setting	▼ Show Time and Packe OverTime: 20 ms No 1 BytesTo 末尾 ▼ VerifyNone ▼									
RTS V DTR BaudRat 9600 V	11 01 01 ED	^								
为了更好地发展SSCOM软件 请您注册嘉立创F结尾客户		~								
【升级到SSCOM5.13.1】★嘉立创PCB打样SMT贴片服务. ★RT—Thread中国人的开源免费操作系统 ★8KM远距离WiFi可自组网 ★新一代WiFi芯片兼容8										
www.daxia.com S:8 R:32	COM14 Opened 9600bps,8,1,None,None	CTS								

Thank You

Cubic Sensor and Instrument Co., Ltd. Tell: +86-027-8162 8827 Fax: +86-027-87401159 Email: info@gassensor.com.cn Web: www.gassensor.com.cn Address: Fenghuang Yuan No.3 Road, Fenghuang Industrial Park, Eastlake Hitech Development Zone, Wuhan 430205, China